



## 1904 GLASS BASKET TROLLEY AND STAND ASSEMBLY INSTRUCTIONS

1) PLACE 1 FRAME ON THE GROUND UPSIDE DOWN AND PUSH CROSS BARS ONTO POST JOINERS AND HAMMER HOME WITH A MALLET



2) FIT 2<sup>ND</sup> FRAME ONTO CROSS BARS AND HAMMER HOME EVENLY



3) STAND UP TROLLEY AND INSTALL RUNNERS TO DESIRED HEIGHTS

